iPad/ForeFlight Preflight Checklist

FOREFLIGHT APP UP TO DATE
Check the App Store to verify you have the latest version of ForeFlight installed.
FOREFLIGHT OPENS & FUNCTIONS NORMALLY
Open and run ForeFlight to make sure the app is functioning normally.
CHARTS & DATABASES DOWNLOADED AND CURRENT
Check the Downloads section of ForeFlight to verify all required charts are downloaded and current.
ROUTES, AIRPORTS, AND BINDERS LOADED
Set favorite airports, routes and chart binders as required for the flight.
IPAD BATTERY CHARGED
Ensure the iPad battery has enough charge to meet the requirements of the flight.
GPS OR ADS-B RECEIVER BATTERY CHARGED
Ensure adequate charge on your wireless receiver's battery.
BACKUP POWER OR CHARGING CABLES AVAILABLE
If required, ensure that a backup battery or charging cable is within reach.
STORAGE/MOUNTING DEVICES AVAILABLE
Attach and secure required mounting devices (e.g. kneeboards, yoke mounts, etc.)
CONFIGURE WIRELESS RADIOS
Set Airplane Mode, Bluetooth, Wi-Fi and Cellular Data to ON/OFF as required.
SET IPAD SCREEN BRIGHTNESS
Clean the iPad screen and dim the screen brightness to conserve battery.